


8a

Axial-Rollköpfe Typen F, FU, F-RN, K, FF


Axial thread rolling head type F, FU, F-RN, K, FF



8b

Axial-Rollköpfe Type AC


Axial thread rolling head type AC



8c

Radial-Rollköpfe Typ E


Radial thread rolling head type E



8d

Tangential-Rollköpfe Typ T

Tangential side rolling attachment type T



¹⁾ Die Pfeile geben die Umformrichtung an
Arrow shows forming direction